

220.02 mm

612 mm




ICE BOID 3PSD9 | ICE BOID 4PSD12

AIR COOLER USER MANUAL


LGA 2066 / 2011 / 1700 / 1851/ 1200 / 115X
AM5/AM4/AM3+/AM3/AM2+/AM2/FM2/FM1

formulav-line.com


Accessories




a. intel LGA 1366 | 1700 | 1200 | 115X



b. intel LGA 2066 | 2011 | 2011-3




Note




INTEL

5 intel LGA 1366 | 1700 | 1200 | 115X




INTEL

5 intel LGA 2066 | 2011 | 2011-3




AMD

6 Remove Bracket




AMD

7 AMD: AM5 | AM4 | AM3+ | AM2+ | AM2 | FM2+ | FM2
FM1




Install Fan

8




Connector

9



Caution

10 Make sure cooler firmly touch CPU



ICE BOID 3PSD9 | ICE BOID 4PSD12

AIR COOLER USER MANUAL



formulav-line.com